

# KEG CHANGE INSTRUCTIONS



CARLSBERG QUALITY  
DISPENSE SYSTEM



Red light indicates keg which requires changing.




Turn off gas feeding empty keg. Remove keg coupler from empty keg and reconnect to new keg.



Turn on gas feeding keg.



Press yellow bleed button at the top of module until beer appears at the pipe.



Turn lever on front of module to 'Clean' and wait until red light extinguishes.



Return lever back down to 'Dispense'. Beer is now ready to serve.



Reduced Wastage & Labour costs by extending the Line Cleaning period



Improved Quality of Serve & Experience



Leading to an Increased Rate of Sale



Consistent Dispense Temperature



Increased Yield



Improves Sustainability

CUSTOMER SERVICES - 08000 854 646